



PlayStation 3 Smart Plate Replacement

Remove the glossy plastic smart plate from the top of your PS3.

Written By: Walter Galan



INTRODUCTION

Use this guide to replace your PlayStation 3's smart plate.



TOOLS:

- [Spudger](#) (1)
 - [T10 Torx Screwdriver](#) (1)
-

Step 1 — Smart Plate



- Use the tip of a spudger to remove the black rubber screw cover from the side of the PS3.
- ⓘ The screw cover may be underneath a warranty sticker. This sticker will change appearance, and show "VOID" after it has been removed.

Step 2



- Remove the single 8.5 mm T10 Security Torx screw from the smart plate.


Step 3



- Pull the smart plate toward the hard drive bay, then lift it off the body of the PS3.

Step 4



 Be sure to keep track of the small metal bracket loosely held in the top cover, if equipped.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 01:59:43 PM.